

OpenAir™

Handheld Tool for VAV Controllers and Communicative Actuators

AST20



Handheld Tool for VAV Compact Controllers and Communicative Actuators Software version V2.31

For configuration and maintenance of OpenAir VAV compact and modular controllers and actuators with Modbus RTU communication:

- G..B181.. VAV compact controllers 5 / 10 Nm (series D or newer)
- ASV181.. VAV modular controller
- G..B111../MO communicative actuators 5 / 10 Nm (no spring-return)
- Monitoring and configuration of VAV controllers and communicative actuators
- Bus configuration of Modbus / BACnet MS/TP field devices
- Mass configuration ("Copying mode")
- Diagnostic and maintenance data
- Access levels for service and OEM



Type summary

Product no.	Stock no.	Operating voltage	Power consumption
AST20	S55499-D165	Powered by field device (AC 24 V \pm 20%)	1.5 VA

Ordering (Example)

Product no.	Stock no.	Description	Quantity
AST20	S55499-D165	Handheld tool for VAV controllers and communicative actuators	1

Delivery

The transport case contains one AST20 handheld tool, one 7-pin cable, and one 6-pin cable.

Equipment combinations

VAV compact /modular controllers GB181.1E/ and ASV181.1E/				
ASN	Stock No.	Datasheet	Technical Basics	Mounting instr.
GB181.1E/3		N2544	D2544	M2544
ASV181.1E/3		N3544	F 3544	M3544
GDB181.1E/KN	S55499-D134	N2547	D2547	M0E47
GLB181.1E/KN	S55499-D135	N3547	P3547	INI3547
GDB181.1E/MO	S55499-D166	AGV/10621822	A6\/10621962	
GLB181.1E/MO	S55499-D167	A0V 1003 1032	A0V 1003 1002	AC) (10522082
GDB181.1E/BA	S55499-D168	AC)/40C24024	AC)/40C240C4	A0V 10523063
GLB181.1E/BA	S55499-D169	AOV 1003 1834	AOV 1003 1804	

Actuators with Modbus RTU communication GB111.1E/MO and GB111.9E/MO				
ASN	Stock No.	Datasheet	Technical Basics	Mounting instr.
GDB111.1E/MO	S55499-D191	ACV/10001111	74694	MAGDA
GLB111.1E/MO	S55499-D199	A6V10881141	24034	M4034
GLB111.9E/MO	S55499-D206	A6V10881143	Z4634	A6V10920701

Spare parts

The connection cables can be obtained as spare parts

Spare part	Material no.
6-pin cable	74 424 0126 0
7-pin cable	74 424 0301 0

Software versions

The Software version can be determined in the Handheld tool settings menu, cf. pages 5-7.

Series information	Series A	Series B
Production period	12/2015 - 01/2017	01/2017
Software version	2.22	2.31

Related documents such as environmental declarations, CE declarations, etc., can be downloaded at the following Internet address: <u>http://siemens.com/bt/download</u>

Notes



National safety regulations

Failure to comply with national safety regulations may result in personal injury and property damage.

• Observe national provisions and comply with the appropriate safety regulations.

Connection to an actuator



1 AST20

- 2 G..B181.1E/.. , ASV181.1E/3, or G..B111../MO
- 3 Strain release strip
- 4 Connection cable (7-pin or 6-pin)

	Note
--	------

7-pin and 6-pin connection cables

Using the wrong connection cable (e.g. 6-pin cable on 7-pin plug) can damage the connected actuator

Maintenance

AST20 handheld tools are maintenance-free. Do not open the AST20 handheld tool.

Disposal



Operation

Basic operation

The AST20 is operated by five keys.

- Keys UP (3) and DOWN (4) are used to navigate to a menu item.
- If pressing ENTER (5) on a highlighted menu item, the value can be changed with UP/DOWN (if not protected or readonly).
- Pressing ENTER confirms the value change.
- By pressing ESCAPE (2), a value change can be cancelled or a menu page can be left to the next higher level.



To reset the AST20, press RESET (1) until the display gets dark. The restart takes ca. 20s.

Access levels

- For VAV controllers, the AST20 supports two access levels, "OEM" and "SVC" (service). The access level is shown in the title bar (see below). The SVC level has some restrictions (Vn value and Vnom cannot be changed, mass configuration is not available).
- To enter the OEM level, navigate to "AST20 settings" and select "Enter OEM password".
- The initial OEM password can be obtained through the local Siemens sales representative. The OEM password can be changed after entering the default password. In case the user-defined OEM-password is lost, the AST20 can be reset to ex-works settings.

Screen

AST20 screen elements

elf-identification [1] [2] [3] ed field device type [5] AST20 <> VAV Modbus 1/1 Of unter (page / pages total) [6] Field device configuration evel (SVC / OEM) Bus configuration Diagnostics and maintenance m (not highlighted) AST20 settings Mass configuration	[4] ÈM ► ►
---	---------------------

The highlighting bar is moved with the UP/DOWN keys, where ENTER either opens the submenu (example 1) or allows changing the selected value using the UP/DOWN keys (example 2).

AST20 <> VAV Modbus	1/1 SVC		Field device configuration	1/2 SVC
Online view	•		Operating mode	VAV mode
Field device configuration			Opening dir	CW
Bus configuration		ENTER	Adaptive pos	Or
Diagnostics and maintenance	•		Vn value	2.04
AST20 settings	•	\rightarrow	Vmin	10%
Mass configuration	•		Vmax	90%
June Constant	-		· · · · · · · · · · · · · · · · · · ·	0070
mple 1: Entering a sub-menu	I		Vnom	450 m3/h
imple 1: Entering a sub-menu	1/2 SVC		Vnom	450 m3/h
Imple 1: Entering a sub-menu Field device configuration	1/2 SVC		Vnom Field device configuration	450 m3/h 1/2 SVC VAV mode
mple 1: Entering a sub-menu Field device configuration Operating mode Opening dir	1/2 SVC VAV mode CW	FNTER	Vnom Field device configuration Operating mode Opening dir	450 m3/h 1/2 SVC VAV mode CW
Field device configuration Operating mode Opening dir Adaptive pos	1/2 SVC VAV mode CW On	ENTER	Vnom Field device configuration Operating mode Opening dir Adaptive pos	450 m3/h 1/2 SVC VAV mode CW Or
Field device configuration Operating mode Opening dir Adaptive pos Vn value	1/2 SVC VAV mode CW On 2.04	ENTER →	Vnom Field device configuration Operating mode Opening dir Adaptive pos Vn value	450 m3/h 1/2 SVC VAV mode CW Or 2.04
Field device configuration Operating mode Opening dir Adaptive pos Vn value Vmin	1/2 SVC VAV mode CW On 2.04 10%	ENTER →	Vnom Field device configuration Operating mode Opening dir Adaptive pos Vn value Vmin	450 m3/h 1/2 SVC VAV mode CW Or 2.04 10%
Field device configuration Operating mode Opening dir Adaptive pos Vn value Vmin Vmax	1/2 SVC VAV mode CW On 2.04 10% 90%	ENTER →	Vnom Field device configuration Operating mode Opening dir Adaptive pos Vn value Vmin Vmax	450 m3/h 1/2 SVC VAV mode CW Or 2.04 10% 90%

Example 2: Changing a value

Menu tree for communicative VAV controllers G..B181.. (excl. G..B181../3)

Title bar		Information on connected device and access level (SVC or OEM)
Onl	ine view	
	Setpoint: flow / pos.	Display of actual setpoint (depends on operating mode)
	Actual flow	Actual flow in % and m ³ /h (or l/s)
	Actual position ¹⁾	Actual relative damper position
	Diff. pressure	Actual differential pressure in Pa
	Override control	Override control: Off, open, close, stop, setpoint
Fiel	d device configuration	
	Operating mode	Operating mode (flow control / position control)
	Opening direction	Opening direction CW or CCW
	Adaptive positioning	Adaptive positioning On or Off
	Vn value ²⁾	Coefficient for nominal differential pressure
	Vmin	Minimum volume flow [%]
	Vmax	Maximum volume flow [%]
	Vnom ²⁾	Nominal volume flow [m3/h] or [l/s]
	Altitude level	Altitude level in 100m steps
	Unit vol. flow	m³/h or l/s
	Unit Vmin & Vmax	Display Vmin / Vmax in absolute $(m^3/h / l/s)$ or in relative units (%)
Bus	s configuration ¹⁾	
	Address	Address for RS-485 networks (Modbus / BACnet MS/TP)
	Baudrate	Baudrate
	Transmission format	Start-/Stopbit, Parity
	Termination	Termination electronically switchable
	Backup Mode	Setpoint monitoring On or Off
	Backup Position	Target position if backup mode entered
	Backup Timeout	Setpoint monitoring waiting time
Dia	gnostics and maintenance	
	Field device info	Basic information on connected device
	Field device statistics	Counters and statistical data of connected device
	OEM default settings 2)	Reset to OEM settings / Read or set OEM settings
AS	C20 settings	
	Authorization level	Change from SVC level to OEM level (password required)
	Handheld tool settings	Settings like language, brightness etc. and software version information
	Enter / change ²⁾ OEM password	Entering password for OEM level, or changing password if in OEM level
	Persistent OEM level 2)	Make OEM level persistent (active after power-off of AST20)
	Logoff OEM 2)	Leave OEM level
Mas	ss configuration	
	Mass configuration	Activates mass configuration: cf. description below
	Resume mass configuration	Resume mass conf. if parameters have been changed on a downloaded configuration
	Address incrementation ¹⁾	Automatically incrementing the address when using mass configuration

¹⁾ Available for Modbus / BACnet MS/TP types

²⁾ Write access only in OEM access level

Menu tree for VAV controllers G..B181../3

Title bar		Information on connected device and access level (SVC or OEM)
Online vi	ew	
Setp	oint: flow / pos.	Display of actual setpoint (depends on operating mode)
Actu	al flow / position	Actual flow or damper position in %
Diff.	pressure	Actual differential pressure in Pa
Over	ride control	Override control: Off, open, close, stop, setpoint
Field dev	ice configuration	
Oper	rating mode	Operating mode (VAV / STP / 3P)
Oper	ning direction	Opening direction CW or CCW
Adap	otive positioning	Adaptive positioning On or Off
Vn v	alue ³⁾	Coefficient for nominal differential pressure
Vmir	1	Minimum volume flow [%]
Vma	x	Maximum volume flow [%]
Vmic	1 ⁴⁾	Mid volume flow [%]
Vnor	n ³⁾	Nominal volume flow [m3/h] or [l/s]
U-się	gnal	Setting for the 0/210V feedback signal to flow or position
Ranç	ge Y-signal	Setting the signal range to 010V or 210V
Ranç	ge U-signal	Setting the signal range to 010V or 210V
Altitu	ıde level	Altitude level in 100m steps
Unit	vol. flow	m³/h or l/s
Unit	Vmin & Vmax	Display Vmin / Vmax in absolute $(m^3/h / l/s)$ or in relative units (%)
Diagnost	ics and maintenance	
Field	device info	Basic info on connected device
Field	device statistics	Counters and statistical data of connected device
OEM	l default settings ³⁾	Reset to OEM settings / Read or set OEM settings
AST20 se	ettings	
Auth	orization level	Change from SVC level to OEM level (password required)
Hand	dheld tool settings	Settings like language, brightness etc. and software version information
Ente	r / change ³⁾ OEM password	Entering password for OEM level, or changing password if in OEM level
Pers	istent OEM level 3)	Make OEM level persistent (active after power-off of AST20)
Logo	off OEM ³⁾	Leave OEM level
Mass cor	figuration	
Mass	s configuration	Activates mass configuration: cf. description below
Resu	ume mass configuration	Resume mass conf. if parameters have been changed on a downloaded configuration

³⁾ Write access only in OEM access level

⁴⁾ Used in STP mode only. Note: Vmax can't be lower than Vmid!

Menu tree for communicative actuators G..B111../MO

Title bar		Information on connected device
Online	view	
Se	etpoint: position	Display of actual setpoint
Ac	ctual position	Actual relative damper position
O	verride control	Override control: Off, open, close, stop, setpoint
Field d	levice configuration	
Op	pening direction	Opening direction CW or CCW
Ac	daptive positioning	Adaptive positioning On or Off
Mi	in. position	Minimum position [%]
Ма	ax. position	Maximum position [%]
St	artup setpoint	Setpoint used after startup until setpoint from controller is received
Bus co	onfiguration	
Ac	ddress	Address for RS-485 networks (Modbus / BACnet MS/TP)
Ba	audrate	Baudrate
Tr	ransmission format	Start-/Stopbit, Parity
Te	ermination	Termination electronically switchable
Ba	ackup Mode	Setpoint monitoring On or Off
Ba	ackup Position	Position if backup mode entered
Ba	ackup Timeout	Monitoring waiting time
Diagno	ostics and maintenance	
Fie	eld device info	Basic information on connected device
Fie	eld device statistics	Counters and statistical data of connected device
AST20	settings	
Ha	andheld tool settings	Settings like language, brightness etc.
Mass c	configuration	
Ма	ass configuration mode	Activates mass configuration: cf. description below
Re	esume mass configuration	Resume mass conf. if parameters have been changed on a downloaded configuration
Ac	ddress incrementation	Automatically incrementing the address when using mass configuration

When using VAV controllers, a distinction between operating and OEM parameters must be made. Operating parameters are being used during the runtime of a VAV controller, whereas OEM Parameters overwrite the operating parameters in case of a full reset. OEM parameteres can only be changed when the access level "OEM" is activated.

Auto calibration (VAV compact controllers / OEM access level)

Path: Diagnostics and maintenance / OEM default settings / Auto calibration

- Connect the VAV controller to the air duct and make sure that the nominal air volume flow is applied in the duct.
- Manually put the damper blade into the "fully open" position using the gear disengagement lever (red switch at the side of the VAV controller)
- Turn auto calibration to "On".
- The AST20 calculates the flow coefficient (Vn value) by measuring the differential pressure for the applied nominal air flow
- The calculated Vn value is written into the operating and into the OEM settings.

Mass configuration (communicative actuators; VAV compact controllers: OEM access level)

Path: Mass configuration

- By turning this function on, the configuration (all parameters that can be set by the user) from one field device is loaded into the AST20 and stored there as a "template".
- The stored configuration can be written into 1..n devices of the same type.
- After writing a stored configuration, changes can be made on the connected field device without losing the stored configuration.
- If a configuration is changed after loading it into a field device, it can be made the new template configuration.
- For Modbus and BACnet devices the bus address can automatically be incremented.

AST20 <> VAV Modbus	00	Uploading
Resume mass configfuration	Off ENTER	Ł
Address incrementation		
o 1: Activating the mass configura non-volatile storage of the AST20	tion mode. The configu	ration of the connected field device is uploaded
p 1: Activating the mass configura non-volatile storage of the AST20	tion mode. The configu	ration of the connected field device is uploaded Downloading
p 1: Activating the mass configura non-volatile storage of the AST20 AST20 <> VAV Modbus Mass configuration mode: Active	tion mode. The configu	ration of the connected field device is uploaded Downloading
ep 1: Activating the mass configurat non-volatile storage of the AST20 AST20 <> VAV Modbus Mass configuration mode: Ac Download stored configurat	tion mode. The configu	ration of the connected field device is uploaded Downloading

Step 2: After connecting the AST20 to the next field device (of the same type), the stored configuration can be donwloaded into this target device.

Mass configuration with change of selected parameters in the target device

AST20 <> VAV Modbus		AST20 <> VAV Modbus	1/1 OEM
Mass configuration mode: Active		Online view	
	ENTER	Field device configuration	•
Download stored configuration		Bus configuration	►
Exit mass configuration mode	\rightarrow	Diagnostics and maintenance	•
		AST20 settings	•
		Mass configuration	•

Step 1: The mass configuration mode can (temporarily) be left after upload of the configuration: Selected parameters can then be changed.

AST20 <> VAV Modbus Mass configuration mode	Off		AST20 <> VAV Modbus Mass configuration mode: Active
Resume mass configuration	On	ENTER	
Address incrementation	Off		Download stored configuration
		\rightarrow	Exit mass configuration mode

Step 2: After making the desired changes, mass configuration can be resumed with the original configuration; or the changed configuration can be made the new "template" configuration by newly activating "mass configuration".

OEM Reset (VAV compact controllers / OEM access level)

Path: Diagnostics and maintenance / OEM default settings / OEM reset

• Triggering this function writes the OEM reset values over the operating values.

Copy working set to OEM values (VAV compact controllers / OEM access level)

Path: Diagnostics and maintenance / OEM default settings

• Triggering this function writes the operating values into the OEM reset values.

Password change

Path: Settings

• The default password can be changed with this function.

Power supply		
Powered by controller		DC 24 V ±20%, 30 mA
		AC 24 V ±20%, 60 mA
Display		
LCD type		STN blue, negative
Resolution		Dot matrix 240 x 128
Backlight		White LEDs
Size	LCD size	93 x 58 mm
	Visible area size	86.15 x 47.78 mm
Visibility angle ¹⁾	Angle from top	41°
	Angle from bottom	21°

 $^{1)}\ensuremath{\,\text{V}}\xspace$ Visibility angle is the angle at which the contrast ratio is greater than 2.

General data		
Dimensions		173.2 x 95.5 x 22.1 mm
Weight	excl. packaging	305 g
	incl. packaging and cables	950 g
Lens		Makrolon 2405, transparent
Keypad		Silicon rubber, RAL7035
Housing	Front housing	Makrolon 6485, RAL7035
	Rear housing	Makrolon 6485, RAL5014
Connection cables		
Cable at handheld tool	Туре	74 424 0117 0
	Length	0.29 m
Cable with 7-pin connector	Туре	74 424 0301 0
	Length	2.6 m
Cable with 6-pin connector	Туре	74 424 0126 0
	Length	2.6 m
Degree of protection		
Degree of protection	Degree of protection acc. to EN 60529	IP65
Safety class	Safety class acc. to EN 60730	
UV protection test level		IEC 60068-2-9, 1.13 kW/m ² , procedure B, 7 cycles
Pollution degree		2
Environmental conditions		
Operation		IEC 60721-3-3
oporation	Temperature	-40 70 °C
	Temperature restriction on LCD	-20 60 °C
	Humidity	5 95% r h (non-condensing)
	Air pressure	Min 700 hPa corresponding to
		Max. 3,000 m above sea level
Transport and storage		IEC 60721-3-2
	Temperature	-4070 °C
	Humidity	595% r.h. (non-condensing)
	Air pressure	Min. 260 hPa, corresponding to
		Max. 10,000 m above sea level

Directives and Standards	
Product standard	EN60730-1
Electromagnetic compatibility (Application)	For residential, commercial and industrial environments
EU Conformity (CE)	8000080607 2)
RCM Conformity	8000080608 ²⁾
FCC	FCC part 15(EMC emission FCC CFR 47 part 15)
F	
Environmental compatibility	

The product environmental declaration A5Q00061135F¹⁾ contains data on environmentally compatible product design and assessments (RoHS compliance, materials composition, packaging, environmental benefit, disposal).

²⁾ The documents can be downloaded from <u>http://siemens.com/bt/download</u>

Dimensions



All measurements in mm

Issued by Siemens Switzerland Ltd Building Technologies Division International Headquarters Theilerstrasse 1a 6300 Zug Switzerland Tel. +41 58-724 24 24 www.siemens.com/buildingtechnologies © Siemens Switzerland Ltd, 2018 Technical specifications and availability subject to change without notice.